

## IR Camera Remote Control

### Overviews:

- Camera Remote, it can be remotely controlled by iPhone, iPad and iPod touch through ultra red ray.



### Features:

- It can be remotely controlled by iPhone, iPad and iPod touch for self-snapshot;
- Self-snapshot can be taken for both front camera and rear camera;
- The receiver is inserted into the headset jack of iPhone, iPad or iPod touch, and the transmitter is remotely controlled by ultra red ray for a range of 10 metres;
- Insert the receiver into the iPhone headset jack, in which the light will flash;
- Easy to take along for the small device;
- Can use wide-angle shooting with the help of a clip and mini tripod;
- CR1225 (3V) battery for receiver, CR1225 (3V) battery for transmitter.

## Operation guide:

### A.Insert battery

- Remove the battery cover for insert the battery;
- Put in one CR1225 (3V) battery in the receiver, one CR1225 (3V) battery in transmitter. (Be careful not to reverse positive / negative electrode);
- Replace the cover.

### B.Photo shooting

- Insert the receiver to iPhone headset jack in which the light will flash
- Use the holder to fix iPhone at the constant place or mini tripod for choosing the right angle;
- Open the camera function of iPhone and confirm front camera or rear camera;

### C.Video recording

- Drag the slider to switch to the camcorder, press the Camera button of the remote control to start and press again to stop;
- The receiver will automatically off after one hour, therefore, if you need to record for over one hour, you have to turn on the remote once again or you can directly stop the recording of iPhone.

### Kindly reminder:

- The receiver input to iPhone will automatically off after one hour, if not input to iPhone, will off after one minute;
- The distance for transmit is 10 metres at indoor area, the distance maybe shorten if under the sunlight.
- For iPad camera remote, you need to use 2 clips. (Buy more clips seperately)

**Important Warnings:**

- Do not subject the unit to excessive force, shock, dust or humid environment;
- Do not immerse the unit in water. If you spill liquid over it, dry it immediately with a soft, lint-free cloth.
- Do not clean the unit with abrasive or corrosive materials;
- Do not tamper with the unit's internal components. This invalidates the warranty
- Only use fresh batteries;
- Images shown in this manual may differ from the actual display;
- When disposing of this product, please obey the environmental protection policy; Do not dispose old batteries as unsorted municipal waste. Collection of such waste separately for special treatment is necessary;
- The technical specifications for this product and the contents of the user manual are subject to change without notice;
- Need to be absorbed in driving the vehicle, please don't try to adjust the holder or mini tripod's angle, so as to avoid personal injury.

**Copyright**

\* iPhone, iTouch, iPad, the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries;

**Compatibility:**

- iPhone 3/3GS
- iPhone 4/4S
- iPhone 5
- iPod touch (with camera)
- iPad 2
- New iPad
- iPad mini

## Accessories (Package Contents):

- Camera Remote Control no need APPs
- Holder to fix
- Cell phone strap
- Battery CR1225(3V) x 4PCS

